

User Guide

Revised in Oct, 2019



AccessPatrol

Version 5.4.2

Endpoint Security Software

AccessPatrol User Guide - Table of Contents

1.0 Introduction to AccessPatrol.....	5
1.1 CurrentWare Components	6
1.2 System Requirements	7
1.3 Installing the CurrentWare Server, Console and Solutions	8
1.4 Installing the CurrentWare Clients	9
1.4.1 Local CurrentWare Client Install.....	9
1.4.2 Remote Client Install	10
1.4.3 Deploy CurrentWare Client by Command Line	12
1.4.4 Deploy CurrentWare Client with a Third-Party Software Delivery Tool or Active Directory	12
1.5 Configuring the CurrentWare Client to Connect to the CurrentWare Server Over the Internet (Port Forwarding)	13
1.5.1 Preparing Your CurrentWare Server	13
1.5.2 Installing the CurrentWare Client	13
1.6 Upgrading the CurrentWare Clients.....	14
1.6.1 Automatic Upgrade of the CurrentWare Clients.....	14
1.6.2 Manual Upgrade of the CurrentWare Clients	14
1.7 Standalone Installation.....	14
1.7.1 Installing the CurrentWare Console, Server and Solution	15
1.7.2 Installing the CurrentWare Client	15
1.7.3 Password Protect the CurrentWare Console	15
1.8 Connecting CurrentWare to your SQL server.....	15
1.8.1 Migrating your Existing CurrentWare Data from Firebird to SQL Server.....	17
2.0 CurrentWare Console Overview.....	18
2.1 Client and Group Management.....	19
2.2 Redirect Clients	20
2.3 Client Settings	22
2.4 Troubleshooting.....	26
2.5 Operators.....	28
2.5.1 Operator Permissions.....	29
2.6 Import Users.....	31
2.7 Database Backup Scheduler.....	33
2.8 Auto Delete Scheduler	34
2.9 Console Settings	35
2.10 Server Settings.....	37
2.11 Log Out.....	37

3.0 Overview of AccessPatrol Functions	38
4.0 Controlling Device Access	39
4.1 Access Permissions	39
4.1.1 Warning Message	41
4.2 Device Scheduler	41
4.3 Allowed List	43
5.0 Device Reports.....	45
5.1 Device Report Options	45
5.1.1 Reporting Type	45
5.1.2 Select Mode	46
5.1.3 Reporting Period.....	46
5.1.4 Output	46
6.0 Email Reports.....	47
6.1 Email Settings	48
7.0 Access Code Generator	50
8.0 AccessPatrol Client Settings.....	52
9.0 Copy Group Settings.....	53
10.0 Mode	54
11.0 CurrentWare Server Manager	55
11.1 Changing the CurrentWare Client and Console Port.....	55
11.2 Stopping the CurrentWare Server Service	57
11.3 CurrentWare Database Selection	57
11.4 Upgrading the CurrentWare Database	58
11.5 Compress the CurrentWare Database.....	58
11.6 Archive and Restore the CurrentWare Database	59
11.7 Repairing the CurrentWare Database.....	60
11.8 Reset Primary Key	61
11.9 Advanced.....	61
12.0 Licensing	63
12.1 Register Your Permanent License key	63
12.2 License Management.....	64
13.0 Uninstall CurrentWare Server, Console and Solutions	65
13.1 Uninstalling the CurrentWare Solutions	65
13.2 Uninstalling the CurrentWare Server and Console.....	65
14.0 Uninstall CurrentWare Client	66
14.1 Uninstall CurrentWare Client from the Console.....	66

14.2 Uninstall CurrentWare Client on the Workstation by Command Line.....	67
14.3 Uninstall CurrentWare Client on the Workstation from the Client Configuration Window.....	67
15.0 Technical Support	68
16.0 Contacts	69

1.0 Introduction to AccessPatrol

AccessPatrol is endpoint security software used for controlling the access of external devices on your network computers.

AccessPatrol Device Security

With the influx of portable storage devices and removable media, data theft is becoming an increasing threat to organizations. Devices such as USB sticks, mobile phones, tablets, media players and external hard drives connect seamlessly to company networks without IT administrators having any knowledge that their company data is being exposed.

Portable devices also provide an easy entryway for infecting systems with viruses or malicious software, thus compromising an organization's network.

Banning these devices in the workplace/schools is becoming increasingly difficult to monitor. As a result, more and more companies are resorting to tools that can prevent users from implementing these devices to their workstations.

CurrentWare's endpoint security solution, AccessPatrol, provides a comprehensive solution for securing company devices to minimize unauthorized access to proprietary information.

1.1 CurrentWare Components

There are four primary components in the CurrentWare Console

CurrentWare Server

This component includes a server Service and database. It houses all the data for the configuration and settings. The CurrentWare Server is the central hub for the CurrentWare Consoles and the CurrentWare Clients to connect to. A Firebird database is used for the data storage.

CurrentWare Console

This component is the management console that the administrator uses to control the functionalities of the CurrentWare Solutions. The administrator will be able to see the connection status of their CurrentWare Clients within the CurrentWare Console.

Multiple consoles can be installed on the same network. Multiple authentications can be assigned to different users to allow or restrict the full functionality of the console.

NOTE: the CurrentWare Server and the Console components are commonly installed on the same computer. Additional CurrentWare Consoles may be installed on other administrators' computers.

CurrentWare Solutions

This component contains different functionalities based on the solution that you are installing. After the installation of a CurrentWare solution, the solution's functions will be embedded on the right-handed side of the CurrentWare Console.

- **BrowseControl:** Web Filtering
- **BrowseReporter:** Internet Tracking and Reporting
- **AccessPatrol:** Endpoint Device Security
- **enPowerManager:** Power Management

CurrentWare Client

This component is to be installed on all computers that need to be managed by the CurrentWare Console. The CurrentWare Clients establish communication to the CurrentWare Server. The client is password protected and runs in stealth mode.

1.2 System Requirements

Hardware Requirement

All components of the CurrentWare Console are supported on desktop computers and server computers with the following specifications.

- **Processor:** any CPU running i3 or similar or faster
- **Memory:** At least 4GB of RAM
- **Disk Space:** At least 500MB of disk space

Software Requirement

All components of the CurrentWare Console are compatible with the following Operating Systems running 32-bit or 64-bit platform.

- **Windows 7 Professional and Ultimate**
- **Windows 8 and 8.1 Professional and Ultimate**
- **Windows 10 Pro and Enterprise**
- **Windows Server 2008, 2012, 2016**

1.3 Installing the CurrentWare Server, Console and Solutions

Follow the instructions below to install the CurrentWare Server, Console and Solutions.

Before you begin your installation:

- Installation of all components must be done with an admin user account.
- The Server and Console components may be installed on the same computer.

1. Download the Setup Files

Download the CurrentWare setup files from our website:

<http://www.currentware.com/download/>

2. Select a Computer to Install the CurrentWare Server and Console

3. Install the CurrentWare Server and Console

1. Unzip the setup file that you downloaded from our website and run the **currentware.exe** to initiate the CurrentWare Console Installation Wizard.
2. Proceed to accept the **License Agreement**.
3. Put in your **User Information** (Full Name and Organization name) and select the software usage for “Anyone who uses this computer” or “Only for me”.
4. Now, select the **CurrentWare Components** that you want to install. For first time installation, click next. The install wizard will automatically select the CurrentWare Console and Server to be installed on your computer.
5. Select the **Solutions** that you want to install.
6. Type in the computer name (or IP address) of your CurrentWare Server. For first time installation, click next. The install wizard will automatically type in your Computer name.
7. The Installer will now proceed to install the CurrentWare Server, Console and the solution(s) on your computer.

1.4 Installing the CurrentWare Clients

Follow the instructions below to install the CurrentWare clients on the computers you want to manage. After a successful installation of the CurrentWare Clients, they will connect to your CurrentWare Server and automatically show up on your CurrentWare Console.

Before you begin your installation:

- Installation of all components must be done with an admin user account.
- To successfully deploy the CurrentWare Client using the **Remote Client Install utility**, please temporarily disable the Windows Firewall on the client computers and disable Window's Simple File Sharing.

There are four ways to deploy the CurrentWare Clients to your workstations.

1. **Local CurrentWare Client Install:** run the *cwClientSetup.exe* file on all the computers you want to manage.
2. **Remote Client Install:** use the built-in *Remote Client Install* tool on the CurrentWare Console to push the CurrentWare Client install to the computers.
3. **Deploy the CurrentWare Client by Command Line:** create a batch file that will install the CurrentWare Client. Run the batch file through *Active Directory* or *Login Script*.
4. **Deploy the CurrentWare Client with a Third-Party Software Delivery Tools:** use third-party software to deploy the *cwClientSetup.exe* file.

1.4.1 Local CurrentWare Client Install

This is the most standard method of installing the CurrentWare Client. Run the *cwClientSetup.exe* file on each computer you want to manage.

The *cwClientSetup.exe* file can be found on the computer that you have installed the CurrentWare Server. This set up file is stored under:

CurrentWare Client Setup File:

C:\Program Files (x86)\CurrentWare\cwClient\cwClientSetup.exe

When you run the *cwClientSetup.exe* on your managed computers, you will need to fill in the following information.

1. Computer Name or IP Address of the CurrentWare Server

Put in the Computer Name or IP address of the CurrentWare Server that you want the client to connect to. Ensure that the managed workstations can establish connections to the CurrentWare Server.

Upon the completion of your CurrentWare Client installation, it will automatically connect to your CurrentWare Console.

1.4.2 Remote Client Install

Before you begin your installation:

- Disable UAC (User Account Control) and Windows Firewall on the client computers


CurrentWare Clients can be remotely installed from the Console. The remote installer can be found on the console under the menu **Install > Remote Client Install**.

1. Browse for the path of the CurrentWare Client setup file, cwClientSetup.exe, on your computer. By default, this file is located in the following folder on the server computer:

C:\Program Files(x86)\CurrentWare\cwClient\cwClientSetup.exe

2. Enter the **Computer name or IP address** of the CurrentWare Server.
3. Select the option to enable or disable **reboot** after the installation (the recommended option is to enable reboot).
4. Select the computers you want to install the CurrentWare Client on:
 - a. You can enter the IP address manually, or
 - b. Click on the Search button to allow CurrentWare to look for the computers on your network, or
 - c. Import from a text file that contains a list of your computers' names or IP addresses.
5. Enter the username and password of an account that has administrative rights to the computers you are installing to.
 - a. If you are a domain admin, put in the username in the format of **Domain\Administrator**
6. The CurrentWare Client will now be deployed to the designated computers.

Remote Client Install

 **Remote Client Install**
Deployment of the CurrentWare Client to the computers on your network

Installer Path

Select the path of the client setup file

C:\Program Files (x86)\CurrentWare\cwClient\cwClientSetup.exe Browse Save

(The default location of the client setup file is: %Program Files (x86)%\CurrentWare\cwClient\)

CurrentWare Server Settings

CurrentWare Server
IP address or Computer name

Reboot Option

☐ Reboot client systems after installation

Reboot Delay: minutes

Note: Please disable the Firewall and UAC on the target computers. Next Cancel

The First screen of the Remote Client Install Window.

If you are encountering the following error messages during the remote client installation, visit this page for help:

<https://www.currentware.com/faqs/remote-client-install/>

1.4.3 Deploy CurrentWare Client by Command Line

The CurrentWare client file can be deployed through a single command line. Below is a list of switches you can along with the command line to deploy the CurrentWare client with the configurations of your choice.

```
e:\cwClientSetup.exe /qn USERPARAMS="-p Admin -ds 192.168.1.100 " /l  
e:\install.log /norestart
```

Switches:

-p	Required parameter (password is Admin)
-ds	CurrentWare Server IP address or Computer name
-rp	New Password (Optional)
-sp	Confirm Password (Optional)
/qn	Quiet Install
/l	Create a log file during the install. Specify the location and name of the log file.
/norestart	Prevents the installer to restart the client computer

In the above example, the network drive is assigned with the letter e:\. The CurrentWare Client set up file is stored on the network drive and the install log file will be created on the network drive after the installation.

1.4.4 Deploy CurrentWare Client with a Third-Party Software Delivery Tool or Active Directory

The CurrentWare Client is packaged as an .exe file and a .msi file. You can find the .msi file as a separate download link from our download page. You can use your company's system deployment tools to deploy the CurrentWare client to your workstations.

Deploy by Customizing the cwClientSetup.msi File

You can take the existing cwClientSetup.msi file and customize it with the proper CurrentWare Server Computer name and other parameters before you deploy the file.

Use a MSI editor (for example, the Orca MSI editor) and modify the following table within the cwClientSetup.msi file:

Table Property	Property USERPARAMS	Value "-p Admin -ds 192.168.1.100"
-------------------	------------------------	---------------------------------------

Change the IP address in the value field to the IP address of your CurrentWare Server.

Deploy the .msi file using a Software Delivery Tool or through Active Directory.

1.5 Configuring the CurrentWare Client to Connect to the CurrentWare Server Over the Internet (Port Forwarding)

To connect your CurrentWare Clients to the CurrentWare Server over the Internet, you will need to port forward the CurrentWare traffic from your network's router to the CurrentWare Server computer.

1.5.1 Preparing Your CurrentWare Server

First, you will need to set up your CurrentWare Server on a network that has a **Public Static IP address** (obtained from your Internet service provider).

Then, you will need to configure your router's setting. On your router's configuration page, go to the Port Forwarding Settings and forward the traffic from the following ports to the IP address of your CurrentWare Server computer.

- **8990 (TCP and UDP)**
- **8991 (TCP and UDP)**
- **8992 (TCP and UDP)**
- **3050 (TCP and UDP)**
- **1024 (TCP and UDP)**
- **1433 (TCP and UDP)** – for SQL Server database only

1.5.2 Installing the CurrentWare Client

Install the CurrentWare Client by running the cwClientSetup.exe file on the Client computer. During the installation, put in the **Public IP address, hostname or DDNS** of the CurrentWare Server's Network.




1.6 Upgrading the CurrentWare Clients

There are two ways to upgrade the CurrentWare clients in version 4 – Automatic upgrade or Manual upgrade.

1.6.1 Automatic Upgrade of the CurrentWare Clients

The client upgrade process can be automated when you upgrade any version of the CurrentWare client to the latest version.

1. On the CurrentWare Console, go to **Install > Auto Upgrade Clients**.
2. Click on the “**Automatically upgrade the CurrentWare Clients on your network...**” checkbox and the CurrentWare Server will push the update to the clients.



The Client upgrade is automatic when this option is enabled.

1.6.2 Manual Upgrade of the CurrentWare Clients

The client upgrade method can be done manually by running the cwClientSetup.exe file on each computer that has a CurrentWare client installed.

1.7 Standalone Installation

Standalone: Installing the CurrentWare Server, Console and Client on the same computer.

1.7.1 Installing the CurrentWare Console, Server and Solution

1. Run the CurrentWare.exe setup file.
2. Accept the terms in the License Agreement.
3. Select the Security Solutions you want to install.
 - a. AccessPatrol: Block USB and external devices.
 - b. BrowseControl: Web Filter and Application Blocking.
 - c. BrowseReporter: Internet Activity Tracking.
 - d. enPowerManager: Remote Power Management.
4. The Installer will proceed to install the CurrentWare Server, Console and Solutions onto your computer.

1.7.2 Installing the CurrentWare Client

1. Run the **cwClientSetup.exe** setup file.
2. When prompted for the CurrentWare Server, put in the word **loopback**. This will make the Client connect to itself.
3. Finish the installation.

1.7.3 Password Protect the CurrentWare Console


1. Launch the CurrentWare Console.
2. Go to Tools > Operators.
3. Click on Add and add an operator with administrator role.
4. Once an administrator has been added, check the option "Enable Password Security".
5. The next time you launch the CurrentWare Console, it will ask you to enter the operator name and password.

1.8 Connecting CurrentWare to your SQL server

The CurrentWare Server database is compatible with Microsoft SQL server (not included in the setup file). Follow the instructions below to connect your CurrentWare Server to your SQL server.

1. Open the CurrentWare Console.


2. Select *Tools > Database Selection*.



3. This will bring up the CurrentWare Server Manager.

4. Select *Database > Selection > SQL Server*.

5. Enter your SQL Server details:



- SQL Server name and Instance.
 - Authentication:
 - i. For workgroup, SQL Server Authentication is required.
 - ii. For Domain, you can choose between SQL Server Authentication or Windows Authentication.
 - Account name and password.
6. A new SQL database called *CWNPSQL.mdf* will be created on your SQL Server.
7. (Optional): A prompt will appear to give you a choice to migrate your existing Firebird database to the new SQL database.


1.8.1 Migrating your Existing CurrentWare Data from Firebird to SQL Server

The data migration utility is presented after connecting your CurrentWare Server to a new SQL Server database.

File location: `\Program Files(x86)\CurrentWare\cwServer\CWDBMigration.exe`

The data migration utility will migrate all of the CurrentWare data from the Firebird to the SQL database. The following data can be included or excluded from the migration:

1. BrowseReporter Tracking Data: URL, Application and Bandwidth.
 - Note: Including bandwidth data will increase the migration time significantly.
2. AccessPatrol Tracking Data.




2.0 CurrentWare Console Overview

The CurrentWare Console is the manager that the administrators will use to control the managed workstations.

The CurrentWare Console contains the following functions:

- **Client and Group Management**
- **Redirect Clients**
- **Client Settings**
- **Operators**
- **Import Users**
- **Options**
- **Log Out**



The CurrentWare Console.

2.1 Client and Group Management

In computer mode, a connected client is represented by a blue computer icon, while an unconnected client is represented by a grey computer icon. In user mode, an active user is represented by a green user icon, while an inactive user is represented by an orange user icon. For ease of management, the workstations and users can be organized into groups.

Create a New Group

To create a new group, from the menu, select **File > Add New Group**.

Or, right click on the computer pane in the CurrentWare console and select **Add New Group**.

Rename a Group

To rename a group, from the menu, select **File > Rename**.

Or, right click on the computer pane in the CurrentWare console and select **Rename**.

Delete a Group

To delete a group, from the menu, select **File > Delete**.

Or, right click on the computer pane in the CurrentWare console and select **Delete**.

Move Computers/Users

On the CurrentWare Console, organization of the computers, users and groups can be accomplished by dragging and dropping the selected computer/user into the group. To facilitate the organization of a large number of computers, users or groups, you can use the **Move Computers/Users** function.


On the CurrentWare Console menu, select **File > Move Computer/Users**. The left-hand side contains the source folder and the right-hand side contains the destination folder. Select the computer(s) you want to move from the source folder, and then select the destination folder. Click on the >> button to move the computers.

2.2 Redirect Clients

Redirect Client is used to move multiple CurrentWare Clients from one CurrentWare Server to another CurrentWare server.

Redirect CurrentWare Clients to this computer

1. On the new CurrentWare Server, launch the CurrentWare Console and access the menu **Tools > Redirect Clients**.
2. Select the option **Redirect CurrentWare Clients to this computer**
3. Enter the CurrentWare Client password. The default password is Admin
4. Select Redirect All CurrentWare Clients.
5. Click on OK.
6. After a brief moment, the CurrentWare Clients will start connecting to this CurrentWare Server



Redirect Clients

Redirect CurrentWare Clients to/from this server

☒ Redirect CurrentWare Clients to this computer
☐ Redirect CurrentWare Clients from this server to another server

Server Name: CurrentWare-PC
Client Password: *****

☒ Redirect all CurrentWare Clients
☐ Redirect Specific CurrentWare Clients

Enter the client computer IPAddress/Name

Computers IP Address Domain/Workgroup


☒ Select all computers

OK Cancel

Redirect CurrentWare Clients to this CurrentWare Server.

Redirect CurrentWare Clients from this server to another server

1. On the old CurrentWare Server, launch the CurrentWare Console and access the menu **Tools > Redirect Clients**.
2. Select the option **Redirect CurrentWare Clients from this server to another server**
3. Enter the name of the new CurrentWare Server
4. Select the computer you want to redirect to the new CurrentWare Server. Only connected computers can be redirected.
5. Click on OK.
6. After a brief moment, the CurrentWare Clients will start connecting to the new CurrentWare Server



Redirect Clients

Redirect CurrentWare Clients to/from this server

☐ Redirect CurrentWare Clients to this computer

☒ Redirect CurrentWare Clients from this server to another server

Server Name

Client Password

☐ Redirect all CurrentWare Clients

☒ Redirect Specific CurrentWare Clients

Enter the client computer IPAddress/Name

Add Computer Import Search

Computers	IP Address	Domain/Workgroup
<input type="checkbox"/> SAI-LAPTOP(44-1C-A8-E4-48...)		
<input type="checkbox"/> WIN10		
<input type="checkbox"/> CW-XPS13		

☐ Select all computers

OK Cancel

Redirect CurrentWare Clients that are connected from the old CurrentWare Server to a new CurrentWare Server.

2.3 Client Settings


The CurrentWare Client settings can be modified in the CurrentWare Console under **Tools > Client Settings**. You can also right click on a group to find the Client Settings.

Change Password

Put in the new CurrentWare Client password to replace the existing CurrentWare Client password. You will need to use the CurrentWare client password if you want to change the client settings, such as IP address or computer name of the CurrentWare Server or the port that the client uses to connect to the CurrentWare Server. By default, the case sensitive Client password is **Admin**.


General

- **Run at Windows Startup:** toggle the option to allow the CurrentWare client service to start every time the workstation boots up.
- **Show in System Tray:** toggle the option to display the CurrentWare icon in the system tray. When this option is enabled, the administrator can double click on the icon, put in the password, to access the CurrentWare Client configuration window.
- **Block admin users from stopping the client:** toggle the option to prevent the users of the workstation to stop the CurrentWare Client service or end the CurrentWare Client process.



Recovery

- The recovery option is for the property of the CurrentWare Client. By default, the option is set to “Restart the Service”. If the CurrentWare Client service was stopped by Windows or software, the default action would be for the Client to restart itself so it can continue to operate. It is best practice to leave this option as “Restart the Service”.



The screenshot shows the 'Client Settings' dialog box with the 'Recovery' tab selected. The dialog has a title bar with a close button. Below the title bar is a header section with a 'Client Settings' icon and the text 'Client password/settings can be changed from here.' Below this is a section for 'Client Settings for Group: Computers' with a 'Change Password' link and two password input fields. The 'Recovery' tab contains three failure scenarios, each with a dropdown menu set to 'Restart the Service'. At the bottom are 'OK', 'Cancel', and 'Apply' buttons.

Client Settings

Client Settings for Group: Computers

Change Password

New Password

Confirm Password

General Recovery Internet Connection Legacy Filtering

First Failure Restart the Service


Second Failure Restart the Service

Subsequent Failure Restart the Service

OK Cancel Apply

Internet Connection

- **Disable QUIC – Quick UDP Internet Connections (experimental network protocol by Google).** BrowseControl controls Internet using the TCP protocol. QUIC uses UDP for Internet traffic on Google Chrome. Since BrowseControl is not filtering the Internet traffic through UDP, QUIC can cause an issue with BrowseControl's filter. This option will disable QUIC on Google Chrome automatically.
- **Disable Cortana Search on Windows 10.** End users can use Windows 10's Cortana search to reach out to the Internet. By enabling this option, it will block the Firewall's outgoing port associated with Cortana and prevent Cortana searches from displaying results from the Internet.




Legacy Filtering

This setting applies to BrowseControl only.

- **Hybrid (LSP/WFP):** Depending on your client computer's operating system, BrowseControl will use LSP or WFP to filter Internet access.

For Windows 7, 8, 2008 and 2012, BrowseControl will filter internet using LSP. For Windows 10 and 2016, BrowseControl will filter Internet using WFP.

- **HTTPS Settings = Simple:** All web filtering (HTTP/HTTPS) in Hybrid (LSP/WFP).
 - **HTTPS Settings = Advanced:** All web filtering (HTTP/HTTPS) in UIA.
- **LSP:** BrowseControl will filter Internet on the client computers using LSP.
 - **HTTPS Settings = Simple:** All web filtering (HTTP/HTTPS) in WFP.
 - **HTTPS Settings = Advanced:** All web filtering (HTTP/HTTPS) in UIA.
- **WFP:** BrowseControl will filter Internet on the client computers using WFP.
 - **HTTPS Settings = Simple:** All web filtering (HTTP/HTTPS) in WFP.
 - **HTTPS Settings = Advanced:** All web filtering (HTTP/HTTPS) in UIA.
- **UIA:** BrowseControl will filter Internet on the client computers using UIA.
 - **HTTPS Settings = Simple:** automatically switch to Advanced.
 - **HTTPS Settings = Advanced:** All web filtering (HTTP/HTTPS) in UIA.




2.4 Troubleshooting

The troubleshooting option allows administrator to perform troubleshooting tasks to resolve errors that are related to the CurrentWare Client.

Client Restart Schedule

Restarting the CurrentWare Client will resolve unexpected issues that can occur on the CurrentWare Client. This option will help the administrator restart the CurrentWare Client automatically during scheduled time.



Use the Client Restart Schedule to automatically restart the CurrentWare Clients.

Viewing Log files

You can use the CurrentWare Console to remotely connect to a client computer to open the CurrentWare Client log files. The following CurrentWare Client log files are available to view remotely:

- **CurrentWare Client Log**
- **Upload Log**
- **Category Log**
- **Blocked URL Log**
- **Advanced Logs**
- **System Reports > Assets**

CurrentWare Client Log

The CurrentWare Client log indicates the status of the Client. This log file can help identify connection issues and version conflicts.

Upload Log

The upload log records the data, tracked by BrowseReporter, which is uploaded to the CurrentWare Server. This log file can help identify issues with BrowseReporter data upload.

Category Log

The category log records the communication between the CurrentWare Client and the Category Filtering Server used by BrowseControl. If the Category Filtering restriction is not working properly, use this log to identify if the client is connected to the server.

Blocked URL Log

The blocked URL log will show you the blocked websites that your end users attempted to access. You can use this log to identify additional websites (such as CDN, image server, CSS, etc.) to add to BrowseControl's Allowed list.

Advanced Logs

Use the CurrentWare advanced log to troubleshoot specific issues that you are having with CurrentWare

- CWSEmail.log
- CWSAPEmail.log
- CWSBRAAlertEmail.log
- CWUserActivity.log
- Advanced client and port connection logs (CltCommand.log, TSTLog8991.log, TSTLog8992.log)

NOTE: Enabling advanced logs may cause your system to slow down. After collecting the log files for the technical support team, remember to disable the logging.

System Reports > Assets

A .csv file containing all of your computer's computer name, IP address, MAC address, Client connection, last connected, last disconnected and user names.

2.5 Operators

Operators are used in the CurrentWare Console to assign console permissions to different users. The Operators utility is available on the CurrentWare Console under **Tools > Operators**. There are two types of operators in CurrentWare Console: Administrator and User.

- **Administrator type** has complete control over every computer, group and the solution's functionalities.
- **User type** has limitations defined by the administrator. These limitations include the solution's functionalities and group accesses.

Password Protect the Console


In order to password protect the console, operator accounts need to be created.

Creating an Operator:

1. Launch the CurrentWare Console.
2. On the menu select **Tools > Operators**.
3. Click on the **Add** button.
4. Fill in the name, password and description.
5. Select a role for this operator. While the **Administrator** role has access to all the features of CurrentWare, the **User** role only has the limited access to the solution's functionalities.
6. Click **OK** to create a new operator.

Enable Password Protected CurrentWare Console

1. Create an operator with the step above.
2. Check the option **Enable Password Security**.
3. Log out of the CurrentWare Console.
4. The next time you log into the CurrentWare Console, you will be prompted for a username and password.



Administrators have unlimited control. Users have limited controls.


2.5.1 Operator Permissions

With operator permissions, you can assign each operator access to specific groups or specific solution operations.

This only applies to an operator with the user role. An operator with administrator role will have access to all groups and all operations.

Assign Access to Groups

Check the checkbox next to the group that you want the operator to have access to. The operator will only be able to see the computers/users under the checked group.



Assign Operations

Each solution along with the CurrentWare Console has specific operations you can assign to a user operator:

CurrentWare Console Operations

- Create/Rename/Delete Groups
- Move Computers/Users
- Client Operations
- Redirect Clients
- Registration & Manage Computers

- Auto Delete URL Scheduler
- Track Assets


BrowseControl Operations

- Internet Settings
- On/Off
- Scheduler
- Timer
- Internet Quota Limit
- URL Filter (Add, Remove, Import and Export)
- Category Filtering
- HTTPS Settings
- App Blocker (Add, Remove, Import, Export and Scheduler)
- Display Warning Message
- Port Filter
- Download Filter
- Copy Group Settings
- BrowseControl Client Settings

2.6 Import Users

The Import users function will import your existing Windows users from your Active Directory domain into the CurrentWare Console.

1. In order to import users, your CurrentWare Console must be in User Mode. Click on the tab called "User Mode" below the toolbar on the left-hand side to activate User Mode.
2. Click on **Tools > Import Users**.
3. Select to Import from **Active Directory** or from a **Text File**.
4. Enter the **Domain administrator** credential (Domain name, user name and password) and click on the Import Users button.
5. A list of your Active Directory Users will be populated in the window.
6. Select specific users you want to add to the CurrentWare Console or click on the checkbox **Select All Users**.
7. Click **Add Users** to add the selected users to the Console.



Import Users

Select the Active Directory Users to be imported to the Currentware Console

Import users from ☒ Active directory ☐ Text file

Domain Details

Domain Name

User Name Password

<input checked="" type="checkbox"/>	User Name	<input checked="" type="checkbox"/> ALL
<input checked="" type="checkbox"/>	Mitchell Bruce	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Nadir Ritter	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Hamaad Garner	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Hakim Long	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Tayla Barker	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Jo Mcfarland	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Tanner White	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Loretta Ryder	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Courtne Sharpe	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Theon Mills	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Harleen Burns	<input checked="" type="checkbox"/>

Import Windows Users from Active Directory.

NOTE: When you import users from Active Directory to the CurrentWare Console as operators, the operator name will be the same as the username on active directory. However, the passwords cannot be retrieved directly from the Microsoft Active Directory for security purposes.

The new password for each operator is the username in lowercases. For example, if your Active Directory username is John, your CurrentWare operator password will be john.

2.7 Database Backup Scheduler


The Database Backup Scheduler automatically backs up the CurrentWare database (CWNPFB.CWD) at a scheduled time.

The database will be backed up into the following default directory:

\Program Files (x86)\CurrentWare\cwServer\Backup

Up to a maximum of 10 of the newest databases will be backed up into the folder.


You can perform a one-time back up by clicking on the “Run Backup Now” button.



Automatically back up your database at a scheduled time.

2.8 Auto Delete Scheduler

Automatically delete URL, bandwidth, application and device histories from your database. An optimized database will improve the performance of the CurrentWare Console and reduce the time it takes to generate reports.



In this example, data older than 180 days will be deleted automatically every day at 9:00 PM.

Only Keep Data for: Select the number of days you want to keep your Internet data. The Auto Delete scheduler will automatically delete any data that are older than the day that you selected.

Start Time: The scheduler will be executed at this time. During the data cleanup, the Console may close briefly (depending on your database size, the time it takes for the cleanup will vary). After the cleanup is completed, you can resume using the CurrentWare Console.

The CurrentWare Server must be turned on at the Start Time for the cleanup process to happen.

Database Compression to reduce file size: Database compression is a heavy process and during the compression, the cwServer will be down. So, we do not perform compression each time the Auto delete scheduler is triggered. Instead, the compression only runs once every 3 schedules and only if the database is larger than 500 MB.


2.9 Console Settings

Details of the Console port and newly connected client management are available on the CurrentWare Console under **Tools > Console Settings**.

General

Add new Computers to the group: define the group that a new computer will automatically be assigned to once it connects to the CurrentWare Server for the first time.


Add new Users to the group: define the group that a new user will automatically be assigned to once it is populated to the CurrentWare Server for the first time.



Connection

CurrentWare Server: The computer name or the IP address of the CurrentWare Server that the CurrentWare Console is connected to.


Console Port: The port that CurrentWare Console uses to connect to the CurrentWare Server. The default Console port is 8990.



Notification

Enable/disable the following notifications:

- Show welcome screen during start up
- Show maintenance reminder after expiry
- Check for updates




2.10 Server Settings

Use the Server Settings to change the CurrentWare Server service start up type and recovery mode.

Server Service Settings

Automatic (Delayed Start): Enable this option if you are having issue with the CurrentWare Server service not starting during boot up.

Restart CurrentWare Server Every 8 hours: Enable this option to reset any CurrentWare Server service issues every 8 hours.



Recovery

The CurrentWare Server service is set to “Restart the Service” if it runs into any failures. This will prevent the CurrentWare Server service from stopping unexpectedly.

2.11 Log Out


Log Out can be used to re-log into the Console with a different user name and password. This feature can be found under the menu **File → Logout**.

3.0 Overview of AccessPatrol Functions

AccessPatrol is an endpoint security tool that allows an administrator to control the device access of your network.

An overview of the AccessPatrol functions includes:

- **Device Blocking**
- **Device Scheduler**
- **Allowed List**
- **Device Reports**
- **Email Reports**
- **Access Code Generator**
- **Mode**



AccessPatrol Solution Features.

4.0 Controlling Device Access

AccessPatrol is a device security tool. It allows administrators to control the access of external devices of the users on the network. Below are the main features of AccessPatrol on the CurrentWare Console.

- **Access Permissions**
- **Device Scheduler**
- **Allowed List**

4.1 Access Permissions

AccessPatrol allows the administrator to control the device access privileges for a group of clients or an individual computer.

Full Access: The computer with this access permission can read and write to the specified external devices that are connected to the computer.

Read Only: The computer with this access permission can only read the information from the specified external device that is connected to the computer. The user will not be able to copy any information to the specified external device. This option is only available to storage devices.

No Access: The computer with this access permission cannot read or write to the specified external devices that are connected to the computer.

In the CurrentWare Console, groups do not inherit settings from their parent groups. The groups store the CurrentWare settings independently.

Here is a list of devices that are supported by AccessPatrol:

Storage Devices:

- USB (Removable disk, iPod)
- CD/DVD
- Floppy
- Tape
- External Hard Drive
- FireWire
- SD Card
- MM Card

Communication Ports:


- Serial
- Parallel

Wireless Devices:

- Bluetooth
- Infrared
- Wi-Fi

Other:

- Imaging Devices (Digital camera, Webcam)
- Portable Devices (iPhone, Mobiles)
- Sound Cards
- USB Ethernet Adapter



AccessPatrol can control multiple endpoint devices.

Blocking External Devices on Your Network


1. Click on a group or a computer.
2. From the AccessPatrol tab, select **Device Blocking**.
3. Select the device you want to control on the left-hand pane.
4. Assign the access permission on the right-hand pane.
5. You can block the access permission for all devices by selecting **All Devices** and assign **No Access** to it.
6. The devices that are blocked will be listed in the CurrentWare Console under the column **Devices Blocked**.

Read Only Permission: Allows the user to read the file but cannot make changes to it. The user will not have the ability to create new files on the controlled devices. Read Only permission is available for storage devices only.

Note for Bluetooth Device blocking: In order to block some Bluetooth devices and its associated services, a reboot may be required on the client's computer.

4.1.1 Warning Message

Display a warning message when your user attempts to access a blocked device.



4.2 Device Scheduler

The device scheduler allows the administrator to assign when the device permissions will be enforced by assigning the start time and stop time for particular devices on the network. Only storage devices are available for the device scheduler.

This is a Group specific setting. Groups can be assigned to three levels of device accesses:

Full Access: The computer with this access permission can read and write to the specified external devices that are connected to the computer.

Read Only: The computer with this access permission can only read the information from the specified external device that is connected to the computer. The user will not be able to copy any information to the specified external device. This option is only available to storage devices.

No Access: The computer with this access permission cannot read or write to the specified external devices that are connected to the computer.

Creating a Device Schedule


1. Highlight the group you want to assign a scheduler to and select **Device Scheduler** under the AccessPatrol tab on the right-hand side of the CurrentWare Console.
2. Click on the **Add** button to create a new schedule.
3. Select the **Device type**.
4. Select the **Access Permission**.
5. Select the **Schedule Type**.
6. Select the **Schedule Reoccurrence**: Daily, Weekly or Monthly.
7. Select the **Schedule Start and Stop Times**.

8. Click on the **Add Schedule** button to create the Device Schedule.

- Up to 20 different device schedules can be set per Group.

9. Click on **Enable Scheduler**.

10. Click on **Apply to Clients**.



The screenshot shows the 'Device Scheduler' window. At the top, it says 'Device Scheduler' and 'Daily and Weekly Device Schedules'. Below this, it indicates the 'Device Schedule for Group: Computers'. There is a table with the following columns: Device, Block Type, Schedule Type, Start Time, Stop Time, and Days. The table contains one row: 'Storage Devices', 'No Access', 'Daily', '9:00 AM', '5:00 PM'. Below the table are buttons for 'Add', 'Edit', and 'Remove'. Under 'Add Device', there is a dropdown menu showing 'Storage Devices' and three radio buttons: 'Full Access', 'Read Only', and 'No Access' (which is selected). Under 'Add Schedule', there is a dropdown menu showing 'Daily', 'Start Time' and 'Stop Time' fields both set to '8:44 PM', and an 'Add Schedule' button. At the bottom, there is a 'Help' link and buttons for 'Enable Scheduler', 'Clear', 'OK', 'Cancel', and 'Apply To Clients'.

Device	Block Type	Schedule Type	Start Time	Stop Time	Days
Storage Devices	No Access	Daily	9:00 AM	5:00 PM	

Buttons: Add, Edit, Remove

Add Device: Storage Devices (dropdown), Full Access, Read Only, No Access (selected)

Add Schedule: Daily (dropdown), Start Time: 8:44 PM, Stop Time: 8:44 PM, Add Schedule button

Daily instructions: For Daily schedule please select Device, Block type, Schedule type, Start Time, Stop Time and press the button "Add Schedule". For Weekly schedule select the weekdays also.

Bottom buttons: Help, Enable Scheduler, Clear, OK, Cancel, Apply To Clients

The Device Scheduler sets the time for the device access to go on and off.

4.3 Allowed List


Administrators can utilize the Allowed List to specify devices that will have permanent access on the network.

By adding a device to the Allowed List, any user on the network will be able to access it even if the device permission is set to No Access.

You can choose to add a single device with a specific serial number or add devices from the same vendor and model.

The allowed list is folder specific. It applies to any computers that are in the specified folder.

The following devices are supported by the allowed list: *USB and External Hard drive.*




The devices listed on the Allowed List have permanent access by the users.

Adding a Device to the Allowed list

1. A device must have been physically connected to a computer where the CurrentWare client is installed at one point in time.
2. Click on a group and select **Allowed List** under the AccessPatrol tab.
3. Click on **Add from Available Devices**.
4. Check the device you want to allow.

5. Choose the option “Allow all devices from the same vendor and model” or “Allow specific device(s) by serial number”.
6. Click on **Add to Allowed List**.
7. Click Ok.
8. Ensure the “**Enable Allowed list**” option is checked.
9. The selected devices will be added to the Allowed list.

Note: Allow a device by serial number is fully compatible with Windows 10. For Windows 7 or 8, some newer models of USB devices may not support this feature. Instead of allowing by serial number, it will allow all devices from the same vendor and model.



5.0 Device Reports

The AccessPatrol reporting utility addresses an organization's security compliance of mobile and storage devices.

It serves as an effective tool for analyzing removable device usage and policy enforcement. Effectively identify employees that frequently abuse the endpoint device policies. Through the intuitive reporting tool, generate comprehensive reports highlighting device usage by computer or by user.

5.1 Device Report Options

In the device report option, you can select the types of device access report that you would like to generate. You can also define the computer and the reporting period for which the report data will reflect on.

5.1.1 Reporting Type

The AccessPatrol reports are clear and easy to understand, ranging from executive level summaries to drill down detailed reports for administrators. The reports include:

- **USB File Operations History:**

Files that were copied, deleted and renamed on your employee's USB devices.

Files that were copied from your employee's hard drives onto their USB devices. Or files that were copied from your employee's USB devices onto their hard drives.

- **All Devices Accessed**

A high-level overview of all the endpoint devices that were plugged into your employee's PC.

- **Allowed Devices**

The allowed devices that were connected to your employee's PC during the report period.

- **Blocked Devices**

The blocked devices that were connected to your employee's PC during the report period.

- **Allowed vs. Denied Access:**

All of the accessed devices (allowed and blocked) with a visual report of their Allowed or Blocked status.

- **Top N Active Machines:**

A high-level overview of each PC and the number of Allowed and Blocked devices that connected to them.

5.1.2 Select Mode

Select the computers or users to generate a device report on. You can select an individual computer, multiple computers and a group of computers. The same selection applies for the users.

5.1.3 Reporting Period

Select the time and date period for the report. The reporting period options are as follow:


- All
- Today
- Yesterday
- Last 7 Days
- Last Month
- Custom Range: day and time range.

5.1.4 Output

You can choose to output some reports in .CSV format for easy access on your spreadsheet program such as Microsoft Excel.

The reports that are compatible with this option are:

- **USB File Operations History**
- **All Devices Accessed**



6.0 Email Reports

Through the Email Reports feature, the AccessPatrol reports can automatically be generated and emailed to the administrator periodically. This eliminates having to rely on the manual process of creating reports.


To access Email Reports, under the AccessPatrol tab, click on **Email Reports**.

How to Create a Schedule for Email Reports:

NOTE: You must have your email settings configured and a report profile created before creating an email report schedule.

1. Under the AccessPatrol tab on the right-hand side of the console, select **Email Reports**.
2. Click on the **Create Schedule** button.
3. Define the **email address** of the recipient of the reports.
4. Select a **Report profile** to generate a report of your choice. A report profile is created in the Report Options menu item.
5. Define the **schedule type (daily or weekly)** of the email report.

6. Define the delivery **time** of the email report.
7. The Internet report will be sent in a PDF format.



Email Reports - To create report profile

Email Reports | **Email Settings**

Assign schedule(s) for Emailing reports

Email Address	Report Profile	Format	Time	Days
info@currentware.com	test	PDF	5:35 PM	

Create Schedule Delete Edit

Assign schedule(s) for Emailing reports

Email reports to: info@currentware.com

Report profile: Daily Report [Help](#) Report format: PDF

Schedule: Daily Time: 5:00 PM Add Schedule Clear

To Email Reports on a regular basis, create a schedule, include the recipient(s) Email address(s), select a Report Profile and the time to send the Email.

OK Cancel Apply


6.1 Email Settings

Under the Email Settings tab, enter the email configuration that is required to successfully send the reports to the administrator.

How to Configure Your Email Settings:

1. Enter the appropriate email information, including the **name**, **email address** and the **password** for your email address.
2. Define the **outgoing mail server** that your email account uses to send email. The default SMTP port that AccessPatrol uses to send email is port 25.
3. Enable **My SMTP server requires authentication** if your email server requires the authentication.
4. You can also use web email services, such as Gmail/ Hotmail/ Yahoo mail, to generate email notifications. These web email services usually require mail server authentication.
5. To test the validity of the email account information, click on the **Test Email Account** button to ensure that the reports will be emailed successfully.

6. Click on the Apply button.



The image shows a Windows-style dialog box titled "Email Reports". It has a tabbed interface with "Email Reports" and "Email Settings". The "Email Settings" tab is active. Under "Email Information", there are fields for Name (CurrentWare), Email Address (info@currentware.com), Password (masked with dots), and Confirm Password (masked with dots). Under "Mail Attachment Encoding", there is a dropdown menu set to "None". Under "Outgoing Mail Server Configuration", there are fields for Outgoing mail server (smtp.currentware.com) and SMTP Port (587). There is a checked checkbox for "My SMTP server requires authentication". Below this, there are radio buttons for "Use same settings as my Email information" (selected) and "Log on using". The "Log on using" section has fields for Account Name and Password. There is also a checked checkbox for "Log on using Secure Password Authentication". A "Test Email Account" button is located at the bottom right of the configuration section. At the very bottom of the dialog are "OK", "Cancel", and "Apply" buttons.

Email Reports

Email Reports - To create report profile

Email Reports | **Email Settings**

Email Information

Set up the Email account to send reports from:

Name: CurrentWare

Email Address: info@currentware.com

Password:

Confirm Password:

Mail Attachment Encoding

Encoding: None

Outgoing Mail Server Configuration

Outgoing mail server: smtp.currentware.com

SMTP Port: 587

☒ My SMTP server requires authentication

☒ Use same settings as my Email information

☐ Log on using

Account Name:

Password:


☒ Log on using Secure Password Authentication

Test Email Account

OK Cancel Apply

7.0 Access Code Generator

Generate an access code to allow your end users temporarily access to their endpoint devices. The access code is unique to each computer that you generate it for. Each access code can only be used once.



The image shows a Windows-style dialog box titled "Access Code Generator". It has a close button (X) in the top right corner. Below the title bar, there is a logo of a padlock and the text "Access Code Generator" in green, followed by the subtitle "Generate Access code to grant temporary access of devices." in blue. A text field labeled "Computer:" contains the text "CurrentWare-PC". Below this is a section titled "Generate Access Code" in blue. Inside this section, there is a label "Access Code expires on :" followed by a date picker showing "6/17/2019" and a dropdown arrow. Below the date picker is a red note: "(Maximum 30 days from the current date.)". Below that is a label "Access duration:" followed by a spinner box showing the number "1" and the word "Hours". Below that is a label "Access Code:" followed by an empty text input field. At the bottom of the dialog, there is a section titled "Instructions:" with a bullet point: "Enter the access code on the client computer from their Control Panel > Grant Access to Endpoint Devices (🔓)". At the very bottom, there are two buttons: "Generate" and "Close".


The administrator can grant end users temporarily access to their end point devices.

Access Code expires on: the code will expire on the expiry date and will no longer be valid. You can only generate an access code 30 days in advance.


Access Duration: this is how long the end user will gain full access for.

Access Code: enter the access code on the end user's computer.

On the client computer, browse to Control Panel > All Control Panel Items > Grant Access to Endpoint Devices:



The end user will access the access code window from their Control Panel



The end user will enter the access code in this window to unlock access to their endpoint devices


Computer	Client Version	IP Address	Devices Blocked
 CurrentWare-PC	5.4.100.0	192.168.8.107	Access Code Activated: 1 hr(s), End Time: 06/17/2019 12:07:00

Once access is granted on the end user's computer, their AccessPatrol status will change on the cwConsole.

8.0 AccessPatrol Client Settings

When the CurrentWare Server becomes unavailable, you can retain the access permission on the computer on your network.

Under the AccessPatrol Client Setting, ensure that you have enabled the option called **Enable Device Blocking**.



Enable Device Blocking will continue to control device access when the CurrentWare Server is unavailable.


9.0 Copy Group Settings

The Copy Group Settings function allows you to easily transfer the group settings from one group to another group.

Source Group: This is the group you want to copy the group settings from.

Settings to Copy: The detail of the group settings that you want to copy.

Destination Group: This is the group(s) you want to copy the group settings to.



Copy the group settings from one group to another folder.

10.0 Mode

Switch between PC or User mode.

PC mode: Control endpoint devices by computers. All users logged into the computer will have the same device blocking policy. Compatible with Device Reports.

User mode: Control endpoint devices by users. Each user logged into the computer will have their own device blocking policy. Compatible with Device Reports.

Notes about User mode:

- **User Mode will not work for Terminal Server.** All concurrent TS users will be free from blocking.

For example, if you have 9 desktops and 1 TS. When you turn user mode on (it's a global setting), the 9 computers will be blocked. The 1 TS will be completely open. Any network with at least 1 TS should be aware that the device access on their TS will be fully opened and cannot be controlled in User mode.

- **For desktop with multiple users - only the last active user's policy will be active.**
For example, if you log in with 3 different users (admin, guest, employee), the last active user will be the active restriction. If employee is the last user logged in, the admin will be restricted as well.
- **AccessPatrol cannot track file operations from users logging in using Remote Desktop**
For example, if you remotely connect to a computer and copy files to a USB device, the file transfer activity will not be tracked because it is a remote user.

11.0 CurrentWare Server Manager


The CurrentWare Server Manager is used to manage the administrative tasks of the CurrentWare Server.

To access the Server Manager, click on the **Start Menu > Programs > CurrentWare > CurrentWare Server Manager**.

11.1 Changing the CurrentWare Client and Console Port

Changes to the Client and Console ports may be required to establish the connections between the CurrentWare server, clients and consoles. For example, if you are using a program that is already utilizing the ports that CurrentWare uses, then you will need to change the ports. Otherwise, please do not modify the Client and Console ports.

The default ports are listed in the screenshot below.




CurrentWare Server Manager.

- **Client Port:** the port connection between the CurrentWare Client and the CurrentWare Server.
- **Console Port:** the port connection between the CurrentWare Client and the CurrentWare Consoles.
- **Upload Port:** the port used to upload BrowseReporter (URL, BW and APP) and AccessPatrol data from the CurrentWare Client to the CurrentWare Server.
- **Firebird Port:** the port connection between the CurrentWare Server and the Firebird database.
- **Message Display Port:** the port used by BrowseControl's Web Filter (UIA) to display the warning messages.
- **Web Service Port:** the alternative port used to upload BrowseReporter (URL, BW and APP) and AccessPatrol data from the CurrentWare Client to the CurrentWare Server.


11.2 Stopping the CurrentWare Server Service

To stop the CurrentWare Server, under the Service tab, click on the button “Stop CurrentWare Server”.



11.3 CurrentWare Database Selection

Database selection lets you choose between using the default Firebird database or your own SQL Server.




11.4 Upgrading the CurrentWare Database

Use this option to upgrade an older CurrentWare database to the same version as the CurrentWare Server.

The CurrentWare database file must be located in:

C:\Program Files(x86)\CurrentWare\cwServer\CWNPFB.CWD

Quick Upgrade: Use this option to perform a quick upgrade of the CurrentWare database. If you run into any issues with the database upgrade, uncheck this option and try again.




11.5 Compress the CurrentWare Database

It is recommended that database compression be performed on a regular basis.

To compress your CurrentWare database:

1. Make sure you have closed the **CurrentWare** Console.
2. Go to the Start menu > Programs > CurrentWare > CurrentWare Server Manager.
3. Under the **Compress** tab, click on the **browse** button and search for your CurrentWare database. By default, the database is located under **C:\Program Files\CurrentWare\cwServer\CWNPFB.CWD**
4. Click on the **Compress** button to begin compressing your database.



11.6 Archive and Restore the CurrentWare Database

Archiving the CurrentWare database will create a copy of your existing database. However, all tracking data from the existing live database will be deleted.

NOTE: Archiving will create a copy of the current database. After the archiving process is completed, the Internet tracking data for BrowseReporter will be deleted. All Computer and User data will be maintained but the corresponding monitoring data will be removed.


To Archive your CurrentWare Database:

1. Under the **Archive and Restore** tab, click on the **Archive** button.
2. A copy of your database will be created under **C:\Program Files\CurrentWare\cwServer\Archive**

Restoring the database will put your current database back to the state it was prior to archiving. The current database will be replaced with the archived database. It is advised that you archive your current database before restoring to a previous database, should you need to retrieve the original data.


Restoring an Archived Database:

1. Under the **Archive and Restore** tab, select the database that you want to restore from the drop-down menu
2. Click on the **Restore** button to begin the process of restoring your archived database.




11.7 Repairing the CurrentWare Database

When you are unable to start the cwServer because the CWNPFb database has been corrupted, use this option to repair your existing database.



11.8 Reset Primary Key


Advanced troubleshooting option for resetting primary key used for the data upload process. Only make changes to this option if it was recommended by the CurrentWare support team.



11.9 Advanced

Enabling Stricter client connection handshake will add another layer of validation to the client connection process.

- **Standard – Computer Name & MAC Address (default)**
Renaming a computer will result in a new computer entry on the CurrentWare Console.
- **Stricter – Computer name & MAC Address**
Renaming a computer will update the existing computer's name on the CurrentWare Console if the MAC address matches an existing computer.
- **Computer Name Only**
Renaming a computer will always result in a new computer entry on the CurrentWare Console.



12.0 Licensing

CurrentWare Solutions are licensed on a per-computer basis for client management.

The evaluation copy of CurrentWare is functional on a maximum of 10 computers for 14 days.

12.1 Register Your Permanent License key

After you have purchased BrowseControl, BrowseReporter, enPowerManager or AccessPatrol from CurrentWare, you will receive an email from our licensing department containing your license key information, which includes the following fields:

1. **Organization's Name**
2. **Number of Licenses**
3. **License key**

To register your license key, follow the steps below:

1. Launch the CurrentWare Console.
2. Go to **Help > Licensing**.
3. From the Solutions drop down box, select the **Solution**.
4. Copy your **Organization's name, number of licenses and Activation Code** from the licensing email sent to you.
5. Click on the **Register** Button.
6. Your CurrentWare Console has now been registered.
7. Click on **Next** to manage the computers you want to apply the license keys to.


12.2 License Management

The License Computers console allows the administrator to select the computers to assign the CurrentWare license to. Depending on the installed status of your CurrentWare clients, the licensing process can be automatic or manual.

Managing Your CurrentWare Licenses

You will need to manage your CurrentWare Licenses if you have applied your license key before installing your CurrentWare Clients.

1. After you install your CurrentWare Clients, launch your CurrentWare Console.
2. Go to **Help > Licensing**.
3. Fill in the fields for the Organization name, solution, mode of license, number of licenses and license key.
4. Click **next**.
5. Now the **License Computers** window will appear. This is where you assign your licenses to your computers. Click on the checkbox to assign a license key to your computer.



Manage your CurrentWare Licenses.

13.0 Uninstall CurrentWare Server, Console and Solutions

13.1 Uninstalling the CurrentWare Solutions

1. On the CurrentWare Console, go to Help > Licensing.
2. Select the solution you want to remove and click the “Remove button”
3. The CurrentWare Console will restart and the selected solution will be removed.

13.2 Uninstalling the CurrentWare Server and Console

The CurrentWare Console and Server can be removed from the Control Panel.

1. Go to Control Panel > Programs > Uninstall a Program.
2. Select CurrentWare and click “Uninstall”.
3. The CurrentWare Server and Console will be uninstalled.

14.0 Uninstall CurrentWare Client


The CurrentWare Client can be uninstalled by three different methods:

- **Uninstall CurrentWare Client from the Console.**
- **Uninstall CurrentWare Client on the workstation by command line.**
- **Uninstall CurrentWare Client on the workstation from the Client Configuration Window.**

14.1 Uninstall CurrentWare Client from the Console

Follow the steps below to uninstall the CurrentWare Client remotely from the CurrentWare Console.

1. Launch the CurrentWare Console.
2. Right click on the computer or the group of computers that you want to uninstall, select **Client Service > Uninstall**.
3. The client will proceed to uninstall.
4. A reboot will be prompted. It is recommended to restart the computer.



14.2 Uninstall CurrentWare Client on the Workstation by Command Line

Follow the steps below to uninstall the CurrentWare Client locally on the workstation by running a command line.

You need to have your CurrentWare Client password in order to uninstall the CurrentWare Client by Command line.

On your CurrentWare Client computer, go to start menu > run > type in the following (for Windows 7, go to the run command box):

For 32-bit Windows PC

C:\Windows\SysWOW64\wcsystck\CwClient.exe -p Admin -u

For 64-bit Windows PC

C:\Windows\SysWOW64\wcsystck\CwClient.exe -p Admin -u

The word “Admin” in the command is the password field. Admin is the default CurrentWare Client password. If you changed the CurrentWare Client password during the installation, please replace Admin with your CurrentWare Client password.

14.3 Uninstall CurrentWare Client on the Workstation from the Client Configuration Window

Follow the steps below to uninstall the CurrentWare Client locally on the workstation from the CurrentWare client configuration Window.

1. On the Client computer, go to C:\Windows\System32\wcsystck (for 32-bit computers) or C:\Windows\SysWOW64\wcsystck (for 64-bit computers).
2. Double click on cwagent.exe.
3. When prompted for the CurrentWare Client password, type it in (Admin is the default CurrentWare Client password. If you changed the CurrentWare Client password during the installation, please replace Admin with your CurrentWare Client password).
4. In the CurrentWare Client Configuration Window, click on the Uninstall button to uninstall the CurrentWare client from your workstation.

15.0 Technical Support

There are several ways to reach our technical support team.

By Email: Send us an email at support@currentware.com

By Phone: Call us at 613-368-4300.

Our hotline is available between 8 AM to 6 PM EST on weekdays.

Live Chat: Chat with a live agent on our website at <https://www.currentware.com>

Our live chat is 24/7.

16.0 Contacts

USA

Codework Inc

1623, Military Rd #556, Niagara Falls, NY 14304-1745, United States of America

Tel: 613-368-4300

Fax: 866-929-9808

Email: info@currentware.com

CANADA

CurrentWare Inc

PO Box 30024 King St PO, Toronto, Ontario, M5V 0A3, Canada

Tel: 613-368-4300

Fax: 866-929-9808

Email: info@currentware.com

EUROPE

CurrentWare Inc

PO Box 30024 King St PO, Toronto, Ontario, M5V 0A3, Canada

Tel: 613-368-4300

Fax: 866-929-9808

Email: info@currentware.com

ASIA

Codework Solutions Pvt Ltd,

'Thapasya', Infopark, Kakkanad, Kochi, Kerala, India – 682030

Tel: +91-484-4055678

Fax: +91-484-4061003

Email: info@codework.com

OTHER COUNTRIES

Please email info@currentware.com for the name of a local reseller in your country.